



QUICK START GUIDE


Visit fjwestcott.com/firmware to download the latest firmware

Included Components & Overview


FJ400 Strobe, FJ400 AC/DC Lithium Polymer Battery, AC Power Adapter & Cord, Frosted Diffusion Dome, Magnetic Reflector (Bowens, 5.5"), Magnetic CC Gel Set, Magnetic Diffusion, USB-A to USB-C Cable, Rapid Box Switch Insert (Bowens)



LCD Displays & Menus




*Indicates Canon camera is set to Continuous Shooting with TTL and HSS disabled. Maximum shoot speed may vary.



1. Channel Selection
2. Groups
3. Canon RT ID Selection




1. Audible Beep
2. Optical Sensor
3. Modeling Lamp



1. Mask Function
2. Mask All
3. Mask Sequence Number



1. Strobe Master Lock
2. Delay
3. Delay Time



- Accessible by holding down the Menu Selection Button to customize default strobe settings.

Introduction

This guide covers setup, controls, and basic operation. Visit fjwestcott.com/4700 and scroll to the Support section to download the complete FJ400 User Manual.



Warning

- **IMPORTANT:** During operation, the flash tube, LED modeling lamp, and select components of the FJ400 strobe temperatures will increase. Please use caution while using to avoid serious burns or injuries.
- Use only with the Westcott FJ400 AC/DC Lithium Polymer Battery and/or AC Power Adapter and Cord.
- Do not touch glass diffusion dome, flash tube, LED modeling lamp, or metal reflector after immediate use to avoid potential injury.
- Never leave unattended around children and/or pets.
- Keep away from fire, water, and moisture.
- Do not submerge in water.
- Avoid drastic temperature changes before, during, or after use.
- Avoid direct skin contact with the flash tube and LED modeling lamp when replacing the flash tube.
- Always remove the FJ400 AC/DC Lithium Polymer Battery from the FJ400 Strobe during travel/storage to avoid accidental operation which could lead to overheating or permanent damage.
- Do not overtighten tilter bracket tension knob or umbrella tension screw.
- Ensure the FJ400 is securely mounted before use.
- Only use compatible modifiers and accessories and ensure they are securely attached to the FJ400 Strobe before use.
- Do not attempt to modify any Westcott products. Contact Westcott for assistance.
- The maximum operating temperature is 32-104°F (0-40°C).

Dual-Stage Heat Protection

The FJ400 is equipped with self-monitoring cooling fans to ensure safe operation. It is also equipped with an automatic shutoff feature. In the rare event that the strobe has reached an unsafe operating temperature, the screen will display **OH** (overheat). Once the unit has cooled, the **OH** will disappear from the screen and it will then be safe to continue operation.

Getting Started

Charging the FJ400 AC/DC Lithium Polymer Battery

The battery can be charged separate of the FJ400 or while attached to the FJ400. In both instances, connect the power cord to the AC Adapter, connect the AC Adapter's barrel plug to the battery AC receptacle, and connect the power cord into a power outlet. The battery charging process is complete when the red indicator light on the AC Adapter turns green.

AC Adapter LED Indicator Light Colors:

- **Green:** AC Adapter is plugged into a power outlet without a battery attached or connected to a fully-charged battery.
- **Red:** AC Adapter is plugged into a power outlet and the battery is currently charging and less than 100% charged.

Attaching the FJ400 AC/DC Lithium Polymer Battery

Attach the FJ400 Battery to the strobe by aligning the silver connection points on the rear of the strobe to the holes on the silver strips located on the back of the battery and slide the battery down until it locks into place.

Removing the FJ400 AC/DC Lithium Polymer Battery

Ensure the FJ400 is **OFF** by long-pressing the **Power | Model** button until the LCD screen turns off. Then, slide the release lock located on top of the battery away from the strobe, gently press the battery up and away from the strobe to remove.

AC Power Operation

1. Ensure the battery charge level is $\geq 25\%$.
2. Ensure the battery is securely attached to the FJ400.
3. Plug the power cord into the AC Adapter.
4. With the strobe powered off, connect the AC Adapter's barrel plug to the battery's AC receptacle.
5. Plug the power cord into a dedicated power outlet.
6. Turn the strobe **ON** by pressing and holding the **Power | Model** button until the start-up screen appears.

DC Power Operation

1. Ensure the FJ400 battery has been fully charged.
2. Ensure the battery is securely attached to the FJ400.
3. Turn the strobe **ON** by pressing and holding the **Power | Model** button until the start-up screen appears.

Mounting

Mounting to a Light Stand

1. Rotate the tilter bracket's handle counterclockwise until the light stand receptacle is perpendicular to the strobe body.
2. Loosen the tension knob located lower on the tilter bracket.
3. Insert the light stand spigot into the FJ400's 5/8"-16 mm tilter bracket receptacle.
4. Tighten the tension knob to secure the strobe to the light stand.

Attaching & Removing Modifiers

Connecting a Bowens Speedring & Modifier

1. Ensure the strobe is turned **OFF** and has cooled for five minutes.
2. Grasp the speedring attached to the modifier and align its three square mounting blocks with the openings located on the face of the strobe.
3. Insert the speedring and turn clockwise until the speedring locks into place.

Removing a Bowens Speedring & Modifier

1. Ensure the strobe is turned **OFF** and has cooled for five minutes.
2. Grasp the speedring attached to the modifier.
3. Slide the strobe's speedring release away from the modifier.
4. Rotate the modifier's speedring counterclockwise until its three square mounting blocks align with the openings. Pull the modifier away from the strobe to release.

Attaching an Umbrella-Based Modifier

1. Ensure the strobe is turned **OFF** and has cooled for five minutes.
2. Grasp the umbrella's shaft and slide into the strobe's umbrella receptacle.
3. Tighten the tension screw to secure the umbrella-based modifier.

Removing an Umbrella Based Modifier

1. Ensure the strobe is turned **OFF** and has cooled for five minutes.
2. Loosen the umbrella tension screw.
3. Grasp the umbrella's shaft and gently slide the umbrella out of the FJ400 umbrella receptacle.

Note:

- **Never force entry or removal of speedring, umbrellas, or modifiers.**
- **Use caution during the removal of modifiers to not damage the flash tube.**
- **Octagonal umbrella shaft may not fit into the FJ400 umbrella receptacle.**

Updating Firmware

The FJ400 strobe is designed with a USB-C port to allow for firmware updates only. Future firmware updates will result in performance enhancements, modified menu options, and improved menu layouts.



The FJ400's firmware version is displayed on the start-up screen. Please visit [fjwestcott.com/firmware](https://www.fjwestcott.com/firmware) to update your FJ400 to the latest firmware. Follow the instructions included with the firmware download to update.

IMPORTANT

- If the FJ400 doesn't display as an external device after being connected to the computer, disconnect the USB cable from both devices, restart the computer, and restart the firmware installation process.
- It's recommended that the firmware update installation process be completed only when the connected computer's power level is $\geq 50\%$. Loss of power of any type during this process could render the FJ400 inoperable and require professional repair.
- Removing the USB-A to USB-C cable from the FJ400 without properly ejecting the FJ400 from your computer could render the strobe inoperable and require professional repair.
- Depending on the operating system and the applications running, copying the firmware from your computer to the FJ400 may take a few minutes and/or halt the copying process. Should this happen, close the copy progress window and try again. Further copying issues may require the computer to be restarted.

Warranty

Westcott's warranty obligations for this product are limited to the following terms.

The F.J. Westcott Co. ("Westcott") warrants this Westcott branded product against defects in materials and workmanship under normal use for a period of ONE (1) YEAR from the date of retail purchase from Westcott or an authorized retailer by the original end-user purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option and to the extent permitted by law, Westcott will either (1) repair the defect at no charge, using new or refurbished replacement parts, or (2) exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product. This Limited Warranty applies only to products manufactured by or for Westcott that can be identified by the Westcott trademark, trade name, or logo affixed to them.

This warranty does not apply to: (a) damage caused by accident, abuse, misuse, flood, fire, earthquake, mold, or other external causes; (b) damage caused by operating the product outside the permitted or intended uses described by Westcott; (c) a product or part that has been modified to alter functionality or capability without the written permission of Westcott; or (d) cosmetic damage, including but not limited to scratches, dents and broken plastic.

Disclaimer: By purchasing, borrowing and/or using this product for any event, both public or private, you, the customer, accepts all responsibility and releases Westcott, and its associates, of any and all liability in the event of manufacturer's defect, malfunction or misuse of the product which may lead to further injuries or complications unforeseen by the user. Westcott is not responsible for any potential or incurred damage caused by failure to properly mount, hang, or store the product, which includes, but is not limited to damage to cameras, electronics, electrical equipment, buildings, building materials, personal injury, death, or disability, fire damage, or any and all other damage not mentioned previously.

Please contact Westcott Customer Support for a Return Authorization Number "RMA" prior to requesting warranty service. This RMA must be clearly written on the outside of the box to the left of the shipping label. Items sent in without pre-authorization or that do not fall under the limited warranty will be returned at the expense of the sender.

Phone: 800-886-1689 / 419-243-7311 (International)

Email: support@fjwestcott.com

Shipping: F.J. Westcott Co, 1425-B Holland Rd. Maumee, OH 43537

Register your new gear online at [FJWESTCOTT.COM/REGISTER](https://www.fjwestcott.com/register)

Visit [WESTCOTTU.COM](https://www.fjwestcott.com) for videos, pro tips, inspiration, and more!

Westcott products are made to the company's traditionally high standards of quality and comply with all applicable government safety regulations and requirements. In an effort to provide the best quality products possible, we periodically make product modifications. Actual products may not be identical to items pictured. Made in China. ©F.J. Westcott Co. All rights reserved. J0622