

Aputure STORM 1200x Reflector Kit Packing Guide

Step 1



Place **Medium Reflector Inner Collar (Part C)** inside the empty case.

Step 2



Place **BM7830 Medium Reflector (Part A)** over the inner collar.

Step 3



Slide **Medium Reflector Outer Spacing Ring (Part D)** over the medium reflector.

Step 4



Place **Medium Reflector End Cap (Part F)** over the medium reflector bowens mount.

Step 5



Place **BM7815 Narrow Reflector (Part B)** over the medium reflector assembly.

Step 6



Outer Spacing Ring for Narrow Reflector (Part F) goes in last and secures the narrow reflector.



Lensrentals