## **FUJIFILM**

DIGITAL CAMERA

- T 4

## **New Features Guide**

Version 1.20

Features added or changed as a result of firmware updates may no longer match the descriptions in the documentation supplied with this product. Visit our website for information on the updates available for different products:

https://fujifilm-x.com/support/download/firmware/

### **Contents**

X-T4 firmware version 1.20 adds or updates the features listed below. For information on earlier versions, visit the following website.

http://fujifilm-dsc.com/en/manual/

Vo.	Description	X-T4	See ===	Ver.
	An AUTO POWER OFF TEMP. item has been			
1	added to <b>POWER MANAGEMENT</b> in the set-	232	1	1.20
	up menu.			



Changes and additions are as follows.

# X-T4 Owner's Manual: 🗐 232 Ver. 1.20 AUTO POWER OFF TEMP.

If its temperature rises beyond a certain point, the camera will first display a message and then, if the temperature rise continues, automatically end shooting and power down. Choose the temperature at which the camera turns off automatically.

Option	Description
	The camera turns off automatically when its temperature reaches the <b>STANDARD</b> value.
HIGH	Shooting can continue at temperatures higher than the STANDARD value, extending the time available to record movies and the like. Because remaining in contact with the camera at these high temperatures could result in low-temperature burns, this option should only be used after mounting the camera on a tripod or taking other steps to avoid prolonged contact with the camera.

### **FUJIFILM**

### **FUJIFILM Corporation**

7-3, AKASAKA 9-CHOME, MINATO-KU, TOKYO 107-0052, JAPAN https://fujifilm-x.com











