

## Using the FluCard with the Pentax 645Z

### Setting up the camera

1. Insert the FluCard into slot 2.
2. Turn the camera on. You'll hear a series of beeps (1 quiet beep, 1 loud beep, 6 loud beeps in a row). The card is ready once all the beeps stop.
3. Format the card to ensure it's ready to go (wrench menu 4). Reset transfer settings to ensure default SSID and password (wrench menu 3, submenu under "Wireless Memory Card").

### Setting up the communication device

1. Turn wi-fi on on your phone, tablet, or computer.
2. Select "FLUCARD\_for\_PENTAX" from the list of access points.
3. Enter the default password "12345678"

### Starting the browser

1. Open a browser window on your device and navigate to 192.168.1.1
2. A message will pop up that says "The SSID and network key are in the factory default state. Change the settings". Tap or click [OK] to proceed.
3. Tap or click the back arrow at the top left twice to get to the menu screen. If you want to alter the name of the SSID or the password, you may do so under the Settings tab. Enjoy!