




C200 Recoil Pro / C200 EVF Recoil Pro


The Canon C200 EVF Recoil is a balanced, shoulder mounted rig that includes our VCT Pro baseplate and C200 Zgrip Trigger Relocator to position camera control at a convenient handgrip. It also includes a custom top plate and Recoil Handle for rock solid mounting for accessories. The C200 Recoil Pro utilizes the Canon camera handle; the camera handle screws back into the Zacuto custom top plate.

Parts & Features


x1 Universal VCT Baseplate




x1 Z-grip Trigger Relocator for C200



x1 C200 Top Plate




x1 Recoil Handle (C200 EVF Recoil)



For additional assembly and individual component features, see numerical figures.

C200 Recoil Pro



C200 EVF Recoil Pro




Figure 1:a Mounting Camera to VCT Pro Baseplate




Figure 1:b Adjusting Rods




Figure 1:c Mounting VCT Pro Baseplate to VCT Tripod Plate (Sold Separately)




Figure 2:a Assembling C200 Zgrip Trigger Relocator




Figure 2:b Operating C200 Zgrip Trigger Relocator




Figure 3:a Assembling C200 Top Plate

Align C200 Top Plate with the holes on the top of the camera, and then screw in the two provided screws.




Figure 3:b Mounting your Recoil Handle (C200 EVF Recoil)




Figure 3:c Operating your Recoil Handle






Figure 3:d Mounting C200 Monitor to C200 Top Plate


For the most compact configuration, orient C200 monitor as shown in picture. Attach C200 monitor to C200 top plate using 1/4"-20 screw.



Assembling Z-Rail Axis Mount (Optional)



Assembling C200 LCD Mount (Optional)



NEED MORE HELP

See front figure for full correct Assembly
Check out our tutorial videos at zacuto.com
For additional accessories visit store.zacuto.com