

DJI GOGGLES

Quick Start Guide

快速入门指南

快速入門指南

クイックスタートガイド

퀵 스타트 가이드

Kurzanleitung

Guía de inicio rápido

Guide de démarrage rapide


Guida di avvio rapido

Snelstartgids

Guia de início rápido


Краткое руководство пользователя

V1.0




DJI Goggles

DJI Goggles are equipped with high-performance displays and an ultra-low latency video downlink for use with DJI™ aircraft, giving you a real-time aerial First Person View (FPV) experience. DJI Goggles can also be used to display HD videos, bringing you an immersive high-definition viewing experience. DJI Goggles support head tracking, allowing aircraft and gimbal to be controlled using head movements, introducing a new style of flying.*




1. Touch Panel
2. Headband
3. Charging Status Indicator
4. Micro USB Port
5. Headband Knob
6. Speaker
7. Power Button
8. Battery Level Indicators
9. Back Button
10. Function Button
11. Link Button
12. Linking Status Indicator
13. IPD (Interpupillary Distance) Knob

14. Lens
15. Proximity Sensor
16. Headband Buckle
17. Heat Vent
18. Micro SD Card Slot
19. 3.5 mm Audio Port
20. HDMI Type-D Port
21. Speaker




* Only some aircraft are supported. Please refer to the User Manual for specific models and operations.


Installation and Wearing




Insert the Headband Buckle into the slot above the DJI Goggles body.



Wear the DJI Goggles and adjust the Headband.




Adjust interpupillary distance.




Flip the DJI Goggles body to see outside.

Check the Battery Level and Charging



Press once to check the battery level.
Press once, then again and hold to turn on/off.



The Battery is fully charged when the Charging Status Indicator or the Battery Level Indicators turn off.

Charge time: ~ 4 hours Maximum run-time: ~ 6 hours

Activation and Connection

First-time activation is required before using your new DJI Goggles.
Ensure all devices are powered on and that the Aircraft is linked with the Remote Controller. Make sure both are updated to the latest firmware versions.

MAVIC™ PRO



OCUSYNC™

Press the Link Buttons on the Mavic Pro and DJI Goggles, or enter Tools > Setting > Linking Setting to connect.

Activate with
DJI GO™ 4 App

Please update the app first.
DJI Assistant 2 can also be used for activation.

INSPIRE™ 2* PHANTOM™ 4 Series



Micro USB cable

* Live view only, support somatic control of focus.
Visit the DJI website for future updates.

Activate with
DJI ASSISTANT™ 2

Download: www.dji.com/dji-goggles

DJI Assistant 2 supports Windows 7 (or later) or OS X 10.11 (or later).


INSPIRE Series PHANTOM 4 PRO+



HDMI cable

Live view only.

Video Play Device




HDMI cable




Connect DJI Goggles to your PC with Micro USB cable, then run DJI Assistant 2 to activate.

Controls



Single Finger Touch / 5D Button*

- Swipe to scroll on the menu
- Tap to confirm



Two Fingers Touch

- Swipe forward/backward to unlock/lock the touch panel
- Swipe upward/downward to exit/enter the shortcut menu



Back Button / C2 Button*


Press to return to the previous menu, or exit the current Intelligent Flight Mode.



Function Button / C1 Button*

Press to show the focus cursor, swipe forward/backward with one finger to zoom in or zoom out. Move your head then tap the touch panel to define the focus point.

* When connected with Mavic Pro, the 5D, C1, and C2 buttons on the remote controller will be used to control the DJI Goggles and their original function is disabled.



Somatic Control

DJI Goggles support head tracking, allowing aircraft and gimbal to be controlled using head movements. Multi Intelligent Flight Modes are also supported.

Only support:
Mavic Pro
Phantom 4 Series

Specifications

Weight (Typical)

DJI Goggles Body: 495 g

Headband: 500 g

Dimensions

DJI Goggles Body: 195 × 155 × 110 mm

Headband (folded): 255 × 205 × 92 mm

Screen Size

5 inch × 2

Screen Resolution

3840 × 1080 (single screen: 1920 × 1080)

Communication Frequency

2.4 GHz

Live View Modes

1080p30, 720p60, 720p30

Battery Capacity

9440 mAh

Operating Temperature Range

32° to 104° F (0° to 40° C)

Charger

Input: 100-240 VAC, 50 / 60 Hz, 0.5 A

Output: 5 V = 3 A / 9 V = 2 A / 12 V = 1.5 A

The content is subject to change.

Download the latest version from
www.dji.com/dji-goggles

DJI is a trademark of DJI.
Copyright © 2017 DJI All Rights Reserved.