





Quick-Start


Leica TL







LIVE-VIEW & PLAY MODE




Swipe  to browse images in Play mode



1. **Enlarge** Unpinch or double tap
2. **Reduce** Pinch or double tap




- ▶ Slide show
- ★ Mark as favorite
- 🔒 Protect
- 📁 Select memory for Play mode
- 📄 Copy data




MENU


Start Screen




MyCamera Menu



Browse menus




Touch to enter function / change settings



WLAN

1. Enter WiFi Menu



2. Turn on 3. Choose

WLAN
DIRECT
ROUTER

Create an Access Point
Enter a Network

WiFi

WLAN



ON



OFF

Do you want to connect
directly to your mobile
device or via a router?



DIRECT



ROUTER




OK



4. Choose

Web Gallery See your Images in
Webbrowser on any device

APP Connection Connctet to App on your
Smart-Device



5. Connect

- Select your Leica TL in WiFi section of
your Smart-Device

- Enter **SSID** and **Password** on your
Smart-Device as shown



6. Edit HOST SETTINGS

WLAN ▶ HOST SETTINGS

Device Name / SSID	Leica-TL-00000000	SET
Password	*****	
Security	WPA/WPA2	
IP	192.168.1.1	
WiFi warning message	RESET	>


↺



tap



double tap



long press,
drag & drop



swipe




reduce





enlarge

PERSONALIZE MYCAMERA-MENU



PERSONALIZE SOFT DIALS



Change aperture value in
Aperture Priority mode (A)
or
Change shutter speed in
Shutter Priority mode (S)

