Video 25 Plus Video 25 Plus FB

Manual Benutzerinformation





© by **sachtler**®. Alle Rechte vorbehalten / All rights reserved

Version: 3.9/02/12

Ausgabedatum / Issue date: 02/12

CE

Bestellnr. / Order no.: sko15t100a

We want you to receive Sachtler products that are always state of the art.

Therefore we reserve the right to make changes based on

technical advances.

Wir wollen, dass Ihre Sachtler Produkte immer auf dem aktuellsten Stand sind.

Deswegen behalten wir uns technische Änderungen vor.

Originalbetriebsanleitung/Original User Manual

sachtler[®] Vitec Group Videocom Division www.vitecgroup.com

Erfurter Strasse 16 Postfach / P.O.BOX 2039

Germany Germany Telefon: (+49) 89 321 58 200 Telefax: (+49) 89 321 58 227 E-Mail: contact@sachtler.de

Homepage: http://www.sachtler.com

Table of contents

Table of contents

1	Safety instructions			
2	Operating elements			
3	Operation			
	3.1	Levelling of the fluid head		
	3.2	Removing of the camera plate		
	3.3	Mounting of the camera		
	3.4	Removing of the camera		
	3.5	Positioning of the camera	3	
	3.6	Adjusting the camera's counterbalance	4	
	3.7	Setting of the damping	5	
	3.8	Brakes	5	
	3.9	Support for viewfinder extension	5	
	3.10	Change of the batteries	5	
	3.11 Transport setting of damping, counterbalance			
		and brakes	6	
4	Technical specifications			
	4.1	General data	7	
	4.2	Dimensions	8	
5	The modular system			
	5.1	Conversion to include different balance plate	9	
	5.2	Conversion of the Video 25 Plus to include flat base	9	
6	Warranty10			



Inhaltsverzeichnis

Inhaltsverzeichnis

1	Sich	Sicherheitshinweise11			
2	Bedi	Bedienelemente11			
3	Betri	eb12			
	3.1	Nivellieren des Fluidkopfes12			
	3.2	Entnehmen der Kameraplatte12			
	3.3	Einsetzen der Kamera12			
	3.4	Entnehmen der Kamera13			
	3.5	Zentrieren des Kameragewichts14			
	3.6	Einstellen der Kamerabalance15			
	3.7	Einstellen der Dämpfung15			
	3.8	Bremsen15			
	3.9	Sucherlupenstütze16			
	3.10	Austausch der Batterien16			
	3.11	Transportstellung von Dämpfung, Gewichtsaus-			
		gleich und Bremsen16			
4	Technische Daten17				
	4.1	Allgemeine Daten17			
	4.2	Abmessungen18			
5	Das 5.1 5.2	Baukastensystem18 Umbau des Fluidkopfes auf andere Balanceplatte19 Umbau des Video 25 Plus auf Flachboden19			
6	Gew	ährleistung20			



sachtler

EC - Declaration of Conformity EG - Konformitätserklärung



Here we declare that this product complies with the requirements of the applied directives, standards and regulations for safety and health, if used for its intended application.

This declaration becomes invalid, if any changes have been made without our agreement.

Hiermit erklären wir, dass das hier genannte Produkt aufgrund seiner Bauart in der von ums in Vorkehr gebrachten Ausführung den Sicherheits- und Gesundheitsanforderungen der zugrundeliegenden hier genannten EG - Rüchtlinien und der genannten Normen entspricht.

Bei einer nicht mit uns abgestimmten Anderung an diesem Proxlukt verliert diese Erklärung ihre Gültigkeit.

Product / Produkt:

Video 25 Plus, Video 25 Plus FB

Components / Komponenton:

2500P, 2501P

Code number (s) / Codenummer(n):

1999 Year of first manufacturing / Ab Baujahr.

EC - Directives: EG - Richtlinien:

2004/108/EG

Electromagnetic Compatibility / Elektromagnetische Verträglichkeit

Standards and Regulations: Normen und Vorschriften:

EN 55103-1:2006 EN 55103-2:2006

Inspector / Profstelle: Camera Dynamics GmbH

Date of Inspection / Prüfdatum:

2010-06

Eching, 25.06.2010

Managing Director






1 Safety instructions

- When the camera is mounted, the clamping screw of the fluid head must only be released if camera and tripod are secured against falling over.
- When placing the camera plate into the fluid head, make sure not to hold fingers within the range of the locking lever, since it will snap back.
- Do not operate the fluid head upside down without the necessary securing devices, i.e. ropes etc.

2 Operating elements





3 Operation

3.1 Levelling of the fluid head (Video 25 Plus only)

The fluid head has a bubble to facilitate levelling.

Apply the vertical brake of the fluid head and hold the camera with one hand. Open the clamping screw of the fluid head and move the head in such a way, that the bubble moves into the levels black circle. Tighten the clamping screw firmly.

Touch Bubble

The fluid head has a self illuminating spirit bubble which allows easy levelling even under unfavourable lighting conditions.

The illumination is activated by strong tapping on the bubble. Depending on the force applied the bubble will glow up to 45 seconds.

3.2 Removing of the camera plate

The fluid head comes with a Touch & Go quick release plate.

- ⇔ Hold the camera plate with one hand.
- Grasp the locking lever with your thumb and index and pull down the red safety button.

3.3 Mounting of the camera

Attach the camera plate to the tripod adapter plate (camera accessory) around the camera's centre of gravity.

- □ Turn the counterbalance knob to position 7.
- Apply horizontal brake and release vertical brake.



Manual Video 25 Plus / FB

The springs of the counterbalance engage automatically by tilting the camera through the horizontal position (audible clicking).

⇒ Lock the head with the tilt safety lock.

The blocking and clicking into position of the tilt safety lock is achieved by pulling out the red knob and turning it 90°. Green marking on the red knob becomes visible. Make sure that the tilt safety lock has engaged. (The head can't be tilted any more.)

- Put the front of the camera plate in place first.
- By fitting the camera onto the head it will lock automatically and the locking lever will snap back audibly into its initial position.

3.4 Removing of the camera

□ Lock the head with the tilt safety lock.

The blocking and clicking into position of the tilt safety lock is achieved by pulling out the red knob and turning it 90°. Green marking on the red knob becomes invisible. Make sure that the tilt safety lock has engaged. (The head can't be tilted any more.)

- ⇔ Hold the camera with one hand.
- □ Grasp the locking lever with your thumb and index and pull down the red safety button.

3.5 Positioning of the camera

- Hold the camera by securing the pan bar.
- Apply horizontal brake and release vertical brake and tilt safety lock by pulling out the red knob and turning it 90°. Green marking on the red knob becomes visible (rocking the pan bars up and down will facilitate this).



⇔ Select 0 on the vertical drag adjustment ring.

⇔ Open the lock of sliding balance plate.

You have to push back red lever underneath the balance plate as far as possible.

- By moving the sliding balance plate forwards and backwards you have to find the position where the camera is balanced horizontally. Rear-heavy cameras are moved to the front, front-heavy cameras are moved to the back. You will find it easier when holding the camera in a horizontal position.
- Lock the sliding balance plate by pulling the red lever into its initial position.

Caution: If you can't manage to centre the camera, you should move the camera plate to a different position on the tripod mounting adapter.

3.6 Adjusting the camera's counterbalance

- ⇔ Hold the camera by securing the pan bar.
- Turn the counterbalance knob to that number which best compensates for the weight of the camera.
- After each spring is released, check if the camera will remain in a tilted position, without moving upwards or downwards significantly.

Please note: A lower counterbalance setting becomes immediately effective in any tilt position. An increase of the counterbalance setting will only be effective in the horizontal position (springs must click in audibly).



Manual Video 25 Plus / FB

3.7 Setting of the Damping

The fluid head is equipped with seven damping levels horizontally and vertically and a zero setting. Turning the vertical or horizontal setting one selects the desired level of the fluid damping. Turn the setting ring to "0" in order to switch off the damping completely.

Make sure that you always turn the setting to the next indexed position. Engage the retainer pins by slowly panning or tilting the camera.

ATTENTION: Panning or tilting the camera with settings between the indexed position can damage the retainer pins and/or disks.

If you set the setting rings on the same index number (e. g. "3") the degree of the horizontal and vertical damping is identical and thus enables precise diagonal panning movements without jerks and vibrations.

3.8 Brakes

The horizontal brake applies the lock for the pan and the vertical brakefor the tilt movement. Both brakes are vibrationless and can be used during shooting.

3.9 Support for viewfinder extension

The fluid head Plus has on both sides a preparation to accept a support system for a viewfinder extension.

3.10 Change of the batteries

The illumination is powered by three standard type button cells (625 U or LR9) located in the battery holder, which can be opened with a sharp object such as a screwdriver.

Make sure to insert the new batteries according to the "plus" and "minus" symbols as indicated in the covering plate.

The batteries last for about 2000 illumination cycles.



3.11 Transport setting of damping, counterbalance and brakes

To ensure smooth operation of the setting rings for the damping over the long life time period of the fluid head, you should turn both setting rings from position "0" to maximum position, before and after the use of the fluid head.

Setting during transportation: the most important issue is to open both brakes - horizontal and vertical. Counterbalance and damping should be set to maximum position.



Technical specifications

4.1 General data

Counterbalance: 18 steps (depends on COG of the camera)

100 mm (4.3 in) sliding range (Video 25 Plus FB) 110 mm (Video 25 Plus) Balance plate:

Grades of drag: horizontall, and vertically 7 each and 0

+90°/-75° Tilt angle:

Panning range: 360°

Temperature range:

-40°C (-40°F) to 60°C (140°F)

Weight: 4.5 kg (9.9 lb) 35 kg (77 lb) Max. load:

Camera fitting: Touch & Go system

Tripod / Pedestal

fitting: Pan bar: 150 mm (6 in) ball / flat base


telescopic with attachment diameter of 18/22 mm (0.7 / 0.8 in),

length 350 to 520 mm (13.8 - 20.5 in)

3 each 625 U or LR969 Batteries:



4.2 Dimensions



5 The modular system

Due to the Video 25 Plus / FB modular design you may perform certain modifications yourself. In order to safe time you can do all work with an allen wrench #4 unless otherwise specified.

The following modifications can be performed:

- Conversion of the fluid head to include different balance plate
- Conversion of Video 25 Plus to include flat base



5.1 Conversion of the fluid head to include different balance plate

Remove the camera plate.

Open the lock of the balance plate by pushing back red lever underneath the balance plate as far as possible.

Keep on moving the balance plate backwards until you see an allen screw in the camera plate's receptacle.

Remove the screw.

Now the balance plate can slide off the base plate. It can be exchanged for a different one with either smaller or bigger camera plate.

Don't forget to tighten again the allen screw in the camera plate's receptacle. It serves as a stopper.

The conversion is done.

5.2 Conversion of the Video 25 Plus to include flat base

Put the Video 25 Plus upside down, so that you can access the bottom of the head.

Next to the centre bolt you will see 4 allen screws. Those have to be unscrewed and the whole piece has to be removed.

Now the Video 25 Plus can be mounted onto flat base tripods and pedestals with 4 bolt flat base directly. For Quickfix mount and all Sachtler pedestals the Multi Disc from the Sachtler accessory range is required.

It is mounted onto the fluid heads 4 bolt flat base.



6 Warranty

Warranty expires if:

The fluid head was operated improperly or not in line with the specified technical data, or

the head housing was opened by unauthorised personnel.

We reserve the right to make changes based on technical advances.

Please register at <u>www.sachtler.com</u> for an extended warranty period.

