How to access AViPAS camera via IP

WINDOWS:

Connect the camera to your computer directly via an Ethernet cable.

On the bottom-right corner of your desktop, right click on the Network icon, then click on the "Open Network and Sharing Center".

				Trou	ublesho	ot problems
				Оре	n Netw	ork and Sharing Center
?	^	ΫŢ	(iii	(1)		

Click on "Ethernet2" -> "Properties" -> double click on "Internet Protocol Version 4(TCP/IPv4)".



For WINDOWS10 users:



For WINDOWS11 users:

Pinned Contract Hope Microsoft Hope	Calendar Microsoft Store	- 8	X Local Account See In	OreDrive	ک Windows Updates Reservat	Water Share Web browing
Recommended Contrive Recently added	Get Stand Vectorer to Wildows	Sottem Depsy soud notication, Depsy soud notication, Market Appr App App App App App App App App Ap	Control Business, montes, montes Control Business, posters, montes Control Business, poster Control Business, posters, montespaces Control Business, contex, montespaces	Ind a setting Ind a setting setting	Press A former Press A	Reconnected Personalization Endogrand, took screen, colore Reconcellent Reconcellent Reconcellent Reconcellent Reconnected Reco

Click on Windows "Start" icon, go to "Settings"; then click "Network & Internet" -> "Change adapter options" -> "Properties" -> double click on "Internet Protocol Version 4(TCP/IPv4)".



Choose "Use the following IP address", change computer "IP address" (referred to as IP1) to be consistent with the camera IP address (referred to as IP2).

For example, **AV-1560/1360/1071/1070 series** default IP address (IP2): <u>192.168.100.88</u>, thus the user may change the computer IP address (IP1) to <u>192.168.100.80</u>. Default gateway: <u>192.168.100.1</u>. Make sure the first 3 sections are the same. Subnet mask: 255.255.255.0. Click "OK".

Internet Protocol Version 4 (TCP/IPv4) Properties	>
---	---

General	
You can get IP settings assigned auto supports this capability. Otherwise, yo administrator for the appropriate IP s	omatically if your network ou need to ask your network settings.
Obtain an IP address automatica	ally
Use the following IP address:	
IP address:	192.168.100.80
Subnet mask:	255.255.255.0
Default gateway:	192.168.100.1
Obtain DNS server address auto	omatically
Use the following DNS server ad	Idresses
Preferred DNS server:	
Alternate DNS server:	· · ·
Validate settings upon exit	Advanced
	OK Cancel

Open a browser, input **192.168.100.88** in the address bar, log in with username: **admin**, password: **admin**.

AV-1082/1081/1080/1250/1251/1281/1280/1362(U)/1361/1562/1563's default IP address (IP2): <u>192.168.5.163</u>, thus the user can change the computer IP address (IP1) to <u>192.168.5.160</u>. Default gateway: <u>192.168.5.1</u>. Make sure the first 3 sections are the same. Subnet mask: 255.255.0. Click "OK".

Internet Protocol Version 4 (TCP/IPv4) Properties 💌
General	
You can get IP settings assigned autom supports this capability. Otherwise, you administrator for the appropriate IP set	natically if your network I need to ask your network ttings.
Obtain an IP address automatical	у
Use the following IP address:	
IP address:	192.168.5.160
Subnet mask:	255.255.255.0
Default gateway:	192.168.5.1
Obtain DNS server address autom	atically
• Use the following DNS server add	resses
Preferred DNS server:	
Alternate DNS server:	
Validate settings upon exit	Advanced
	OK Cancel

Open a browser, input **192.168.5.163** in the address bar, log in with user name: **admin**, password: **admin**.

AV-2020/2010's default IP address (IP2): <u>192.168.1.188</u>, thus the user can change the computer IP address (IP1) to <u>192.168.1.100</u>. Default gateway: <u>192.168.1.1</u>. Make sure the first 3 sections are the same. Subnet mask: 255.255.255.0. Click "OK".

General	
You can get IP settings assigned autor this capability. Otherwise, you need to for the appropriate IP settings.	natically if your network supports ask your network administrator
Obtain an IP address automatical	ly
Use the following IP address:	
IP address:	192.168.1.100
S <u>u</u> bnet mask:	255.255.255.0
Default gateway:	192.168.1.1
Obtain DNS server address auton	natically
• Use the following DNS server add	resses:
Preferred DNS server:	
Alternate DNS server:	
Validate settings upon exit	Ad <u>v</u> anced
	OK Cancel

Open a browser, input **192.168.1.188** in the address bar, log in with user name: **admin**, password: **admin**.

For MAC:

Connect the camera with your computer via Ethernet cable.

From the Apple menu, select System Preferences.

Select Network. The window shown below appears.

	Location:	Work		\$
Wi-Fi Connected	(10-	Status:	Connected	Turn Wi-Fi Off
Ethernet Not Connected	~~ >		Wi-Fi is connected IP address 10.0.1.	d to Tony Stark and has the 8.
Display Ethernet	~··>	Network Name:	Tony Stark	\$
FireWire Not Connected	¥		Ask to join n Known networks	will be joined automatically.
FireWire Not Connected Display FireWire	Y Y		Ask to join n Known networks If no known netw have to manually	ew networks will be joined automatically. works are available, you will y select a network.
FireWire Not Connected Display FireWire Not Connected iPhone USB Not Connected	¥ ¥		Ask to join n Known networks If no known netw have to manually	ew networks will be joined automatically. works are available, you will r select a network.
FireWire Not Connected Display FireWire Not Connected iPhone USB Not Connected	₹ ¥		Ask to join n Known networks If no known netw have to manually	ew networks will be joined automatically. vorks are available, you will / select a network.

From the sidebar, select an active network interface. When the camera is connected to your Mac, both Wi-Fi and Ethernet options should be active.

Select **Wi-Fi** first, make a note of the current IP address assigned to your Mac. That's your router's IP address (referred to as IP1), which is not relevant if the camera is connected to your MAC directly.

Then select Ethernet. Click Advanced.

Select **TCP/IP**. The window shown below appears.

From the **Configure IPv4** menu, select **Manually**.

Change IPv4 Address (referred to as IP2) to be consistent with the camera IP address (referred to as IP3). For example, **AV-1560/1070 series** default IP address (IP3): <u>192.168.100.</u>88, thus the user may change the computer IP address (IP2) to <u>192.168.100.</u>80. Router: <u>192.168.100.1</u>. Make sure the first 3 sections are the same. Subnet mask: 255.255.255.0. Click "OK", then "Apply".

Configure IPv4:	Manually	\$
IPv4 Address:	192 . 168 . 100 . 100	
Subnet Mask:	255.255.255.0	
Router:	192.168.100.1	
Configure IPv6:	Automatically	\$

AV-1563/1562/1361/1362/1080/1280/1250 series default IP address (IP3): <u>192.168.5.</u>163, thus the user may change the computer IP address (IP2) to <u>192.168.5.</u>160. Router: <u>192.168.5.1</u>. Make sure the first 3 sections are the same. Subnet mask: 255.255.255.0. Click "OK", then "Apply".

	indiana	•	
IPv4 Address:	192 . 168 . 5 . 100		
Subnet Mask:	255 . 255 . 255 . 0		
Router:	192.168.5.1		
Configure IPv6:	Automatically	\$	

AV-2020/2010 series default IP address (IP3): <u>192.168.1.</u>188, thus the user may change the computer IP address (IP2) to <u>192.168.1.</u>100. Router: <u>192.168.1.1</u>. Make sure the first 3 sections are the same. Subnet mask: 255.255.255.0. Click "OK", then "Apply".

Wi-Fi T	CP/IP DNS WINS	802.1X	Proxies	Hardware
Configure IPv4:	Manually		\$	
IPv4 Address:	192.168.1.100			
Subnet Mask:	255.255.255.0			
Router:	192.168.1.1			
Configure IPv6:	Automatically		\$	
Router:				
IPv6 Address:				
Prefix Length:				

Then open a browser, input the IP address of your camera in the address bar

AV-1560/1070/1071: <u>192.168.100.</u>88

AV-1563/1562/1361/1362(U)/1080/1081/1082/1280/1281/1250/1251: <u>192.168.5.</u>163

AV-2020/2010: <u>192.168.1.</u>188,

log in with user name: admin, password: admin.