

## Safety

1. To prevent possible hearing damage, do not listen at high volume levels for long periods.
2. Risk of explosion if battery is replaced by an incorrect type, dispose of battery according to the instruction.
3. Recycle your products  
The WEEE logo (shown at right) appears on the product to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by transporting to an appropriate collection point for recycling of such hazardous waste.



**FCC Radiation Exposure Statement:** This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

**IC Warning:**  
This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en

**IC Radiation Exposure Statement:**  
This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

### FCC Notice

This device complies with Part 15 of FCC rules. Operation is subject to the following 2 conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## Warranty

All UltraLITE headsets are warranted against defects in material and/or factory workmanship for a period of one year from the date of purchase. Standard repairs due to misuse or wear and tear, as well as replacement parts including but not limited to batteries, padding, USB cable, etc. are excluded. Shipping is to Eartec at customer's expense, Eartec will pay for return ground shipping if the product warranty applies to the repair.

## Shipping

Prior to returning your headset for warranty or service you must call Eartec for an RA (Return Authorization) number: 1 (401) 782-4966

## General Service

All repair work will be performed for the cost of replacement parts and return shipping from the Eartec factory.

Service  
Eartec Co Inc  
145 Dean Knauss Dr  
Narragansett RI 02882



www.eartec.com

1.800.399.5994



**EXCELLENT PERFORMANCE**  
Effective range up to 1/4 mile.

**WEAR ON LEFT OR RIGHT EAR**  
Mic boom swivels 270 degrees.


**LITHIUM BATTERIES**  
Provide continuous 6 hr operation and are field replaceable.

**DECT TECHNOLOGY**  
(DIGITAL ENHANCED CORDLESS TELECOMMUNICATION)

# The UltraLITE

Communicate in Total Comfort

Full Duplex Wireless System



## IMPORTANT

UltraLITE systems include one headset labeled "MAIN".



This MAIN headset must be turned "ON" to link the corresponding REMOTE headsets.

## Battery

All UltraLITE headsets are powered by a Lithium Polymer battery that will operate 6 hours when fully charged.

### Charging

- 1) Batteries are charged via the multi-charger.
- 2) Insert the batteries making sure the contacts are properly aligned.
- 3) RED: Charging; GREEN: Fully Charged.



### Installation

- 1) Press the release button located on the bottom of the battery compartment.
- 2) Insert the battery into the compartment (arrow indicates proper direction) and snap door closed.



### Low Indicator

A repetitive beep (every 20 seconds) indicates low power – battery should be charged or replaced.

## Battery Care

To ensure optimum charge level remove battery from headsets when system not in use.

*(Note: Blue LED on headsets indicates pairing mode. When headset blue LED is NOT illuminated, this does NOT necessarily indicate that the headset is off. Please check switch on Main headset to ensure that it is in OFF position. The battery will continue to drain if left in the headset, and the switch is not turned to OFF position.)*

## Operation



### Adjusting for Fit & Performance


- 1) Adjust the headband slides for size as necessary.
- 2) Position the microphone capsule at one finger's width from the corner of your mouth to ensure superior speech recognition and noise cancellation.
- 3) "TALK" identifies front of microphone: always have this indicator facing towards your mouth.

### STARTUP

- 1) Turn ON the MAIN headset, switch is located below battery compartment. Flashing blue LED on earcup confirms headset is in search mode.
- 2) Turn ON the REMOTE headset(s), press the power button located above volume controls.. Flashing blue LED on earcup confirms headset is in search mode.
- 3) Flashing LEDs change to solid blue to indicate that headsets are connected.



MAIN ON/OFF



REMOTE ON/OFF



### SET VOLUME

UltraLITE features 5 volume settings. Select the desired volume by slowly clicking the UP or DOWN buttons. An audible tone reflects volume level. A double tone indicates low or max volume has been reached.

### SHUT DOWN


Power OFF the MAIN headset utilizing switch, then PRESS and HOLD the power button on the Remote headset(s) for 4-5 seconds to turn off.

*(Note: Blue LED on headsets indicates pairing mode. When headset blue LED is NOT illuminated, this does NOT necessarily indicate that the headset is off. Please check switch on Main headset to ensure that it is in OFF position. The battery will continue to drain if left in the headset, and the switch is not turned to OFF position.)*

## AutoMute Function



Boom swivels over the top 270 degrees. Headset can be worn on left or right ear.



Microphone mutes automatically when boom is set to "UP" position.