

WATSON®

2-Bay Charger

for 9 V Li-ion and NiMH / NiCd
Rechargeable Batteries

9V-2BC-UC

Owner's Manual

FEATURES:

- Two independent charging channels
- Two-color charging status LEDs
- Automatic safety shutoff
- Reverse polarity detection
- Protection against short circuits and power surges
- Includes USB-C to USB-A cable and USB power adapter
- Universal 100-240 V AC input for worldwide use




***Recommended:** For optimal charging, use a USB power adapter with 1 amp or greater.*

SAFETY WARNINGS:

- Do not charge any battery other than the one intended for this charger. Other types of batteries can burst, causing personal injury and damage.
- Make sure to correctly insert the 9 V battery according to the (+/-) polarity symbols shown on the charger.
- Do not disassemble the charger. Take the charger to a qualified service technician when service or repair is required. Improper assembly may result in electric shock or fire.
- Do not operate the charger if it has received a sharp blow or has been dropped or damaged in any way.
- Never expose the charger to rain or moisture.
- Do not use an extension cord when using the charger. This can result in electric shock or fire.
- Never use the charger as a DC power source for any electrical equipment.

- Always unplug the charger from the AC outlet before handling the batteries.
- Unplug the charger from the AC outlet before attempting maintenance or cleaning.
- Do not use any attachment not recommended or sold by Watson, as this could result in electric shock, fire, or injury.

SPECIFICATIONS:

Input Power	Input: 100-240 V AC, 50/60 Hz; Output: DC 5 V = 1 A
Charger Output	9 V Li-ion: DC 8.4 V / 260 mA 9 V NiMH / NiCd: DC 9V / 80 mA
Operating Temperature	-4°F to 113°F (-20°C to 45°C)
Dimensions (H × W × D)	1 × 2.5 × 3 in. (2.5 × 6.4 × 7.6 cm)
Charger Weight	1.5 oz. (42 g)
Certifications	CE
LED status	 Battery charging  Battery charged  Battery error

ONE-YEAR LIMITED WARRANTY

This Watson product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function. This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state. To obtain warranty coverage, contact the Watson Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Watson along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense. For more information or to arrange service, visit www.poweredbywatson.com or call Customer Service at 212-594-2353.

Product warranty provided by
the Gradus Group.

www.gradusgroup.com

Watson is a registered trademark of the Gradus Group.

© 2025 Gradus Group LLC. All Rights Reserved.

